


## Idle speed adjustment (V12)



Auxiliary Air Valve (idle speed controller)

Adjustment screw (13 or 19mm)

With engine fully hot and aircon switched off, adjust engine speed to around 800rpm. Turn screw clockwise to reduce engine speed and vice versa.

Engaging aircon will result in a reduction of engine revs of about 100 when the compressor clutch engages.